



Reset Button    Mic Input    Speaker Output    Volume Control

Audio Control Satellite Board

(Connects to Right of Serial Port)

Video Control Satellite Board

Settings:

E2 - E3    IRQ 5 on bus    (default)  
 E3 - E4    IRQ 5 set for Video Sync

Video Interrupt Jumper.

E1-E2 Microphone \*    (default)  
 E2-E3 Line-audio output

Microphone/Line Audio Jumper

\*Note: This jumper is located on the audio control satellite board.