



1. VIDEO SCREEN
2. POWER ON INDICATOR. This indicator illuminates when power is on.
3. POWER ON/OFF SWITCH. Press to turn power on. Press again to turn power off.
4. VOLUME. Rotary Controls.
5. CONTRAST. Rotary Controls.
6. CONTROL BOX PANEL
7. BRIGHT CONTROL
8. TINT CONTROL
9. COLOR CONTROL
10. EARPHONE JACK
11. VIDEO AND AUDIO RCA CONNECTOR. Connect the Video and Audio Monitor-to-Computer cable to this connector. Connect the other end to the computer's interface.
12. POWER CORD. Plug the power cord into a standard AC outlet (120V 60Hz AC) or UL approved power strip.
13. FOCUS
14. VERTICAL HOLD

(css 07/27/93)

□