

SWITCH	POSITION	DESCRIPTION
1	UP DOWN (+)	Designates COM2 port; I/O address range 2F8-2FF. Designates COM1 port; I/O address range 3F8-3ff.
2	--	Not used.
3	UP DOWN (+)	Modem assumes a carrier signal is always present; Carrier Detect bit is set to logic 1. Modem detects presence and absence of a carrier signal from the remote modem.
4	UP (+) DOWN	When the DTR bit (in the modem's UART Modem Control Register) goes low, the modem hangs up if on-line and returns to the command state. DTR bit ignored.

(+) Indicates default position

(abo-07/29/93)