

Indicator	Status	Indicates that the TAD-410 is:
POWER	Steady	The TAD-410 is turned on and is ready to operate.
ANSWER	Steady	The TAD-410 is ready to receive calls in the answer mode.
	Slow Flash	The TAD-410 has recorded at least one new incoming message. (It is still in the answer mode and ready to receive calls)
	Fast Flash	The TAD-410 is answering a call.
	Off	The TAD-410 is in the other modes than ANSWER.
MEMO	Steady	The TAD-410 is ready to record the outgoing announcement or a memo.
	Slow Flash	The TAD-410 has recorded a new memo.
	Fast Flash	The TAD-410 is rewinding the outgoing tape to the beginning in ANN. RECORD mode.
ANSWER AND MEMO	ANSWER- Slow Flash	The incoming tape has come to the end during recording an incoming message.
	MEMO- Fast Flash	
	Both Slow Flash	The TAD-410 has recorded both a new incoming message and a new memo
	Continuous Three Fast Flashes	The outgoing tape has come to the end while recording the outgoing announcement. The outgoing or incoming tape is torn. The microprocessor in the TAD has become "confused" by conflicting instructions.