


**RADIO CONTROLLED SNEAKER
RECEIVER SHEET # 1 (60-4118)
FAXBACK DOC # 10179**



**CONTINUED ON
SHEET # 2**

RADIO-CONTROLLED SNEAKER
RECEIVER SHEET # 2 (60-4118)
FAXBACK DOC # 10179



CONTINUED ON
SHEET # 1