

If at any time you suspect that your transceiver is not working properly, refer to the following chart to see if you can eliminate the problem.

If the problem persists, take the transceiver to your local Radio Shack store for assistance. Do not attempt to make repairs or adjustments yourself.

| PROBLEM | SOLUTION |
|-----------------------------------|--|
| Trouble receiving. | Check to see if the transceiver is turned on. Adjust volume. Turn SQUELCH to the left. Check for a good antenna connection. |
| Trouble transmitting. | Secure the antenna connector. Clean and tighten all connectors. Be sure you are pressing PUSH TO TALK all the way in. |
| Transmitter does not work at all. | Recharge the battery pack. |

FCC INFORMATION

Your transceiver might cause TV or radio interference even when it is operating properly. To determine whether your transceiver is causing the interference, turn off your transceiver. If the interference goes away, your transceiver is causing the interference. Try to eliminate the interference by:

Moving your transceiver away from the receiver.

Contacting your local Radio Shack store for help.

If you cannot eliminate the interference, the FCC requires that you stop using your transceiver.

(ALL-11/09/94)